



2012 Polaris 600R IQ Race Tip 1



Cut 3 sections of $\frac{3}{4}$ " I.D. pvc pipe to align limiter straps. The center section should be cut to 2" long and the two outer sections to 1.5" long.



With the front track shock installed in the skid frame and the correct preload set on the coil spring, wrap duct tape around the spring, spring clip and shock shaft loop.