



POLARIS[®]

RACING

The rear coupling blocks on the 2014 600R IQ are installed in the Medium setting position. The recommended coupling block position is the Low setting (see picture below). Loosen the bolt on the rear coupling block cross shaft and rotate the blocks to the Low setting. Be sure to align the coupling blocks with the pivot arm.

